





## DVR: Recording Shows





### Recording a Show

You can easily record shows while you're watching them or set up future shows to record. Record up to 40 hours so you never miss your favorite shows.

### Record While You're Watching

1. Any time you're watching a program, you can start recording at the touch of a button. Just press the **RECORD** button . Then press the **A** button  to accept. Your show will be recorded.
2. You can start recording *any time* within the first hour of a show you've been watching since the beginning, and your DVR will still save the *entire* show.
3. You can repeat the process to record a second show that's on at the same time. While both of these are recording, you can watch a third *recorded* show.
4. At any time, to verify your show is recording, press the **INFO** button . The **RECORD** button  will be displayed in the channel banner, along with show information to let you know your program is being recorded.

### Recording Future Shows




1. You can select future shows to record using the program guide. Press the **GUIDE** button. 
2. Use the **UP/DOWN, LEFT/RIGHT** arrow buttons  to browse through the show listings, and time periods.
3. Once the show you want is highlighted, press the **RECORD** button .
4. Press the **A** button  to accept. Your program is now highlighted in red on the program guide, and is set to record.

### Recording Options

You can get more options that allow you to fine-tune your recording choices. Here are some of the most common options:




#### **Option 1: Extend Recording Time**

**Tip:** This is great for when you're recording a sporting event that may go into overtime or an awards show that's running long.

1. After setting up a recording (see steps above), press the **LIST** button  to view your list of chosen shows.
2. Press the **B** button  to choose your list of Scheduled Recordings.
3. Select a show with the **UP/DOWN** arrow buttons and press the **SELECT** button.
4. Use the **UP/DOWN** arrow buttons to highlight either the **Start Time** or **End Time** option. The default option is set to record **On Time**. Use the **LEFT/RIGHT** arrow buttons to choose the number of additional minutes before or after the event you want to record.
5. Press the **A** button  to accept.

### ***Option 2: Saving Your Shows***

This allows you to choose how long your recorded shows will be saved.

1. After setting up a recording (see steps above), press the **LIST** button  to view your list of chosen shows.
2. Press the **A** button  to choose your list of Scheduled Recordings.
3. Select a show with the **UP/DOWN** arrow buttons and press the **SELECT** button.
4. Use the **UP/DOWN** arrow buttons to highlight **Change Save Time**.
5. Use the **UP/DOWN** arrow buttons to choose **Until I erase** (this will save your show until YOU actually erase it. This is the safest option for your most important recordings).
6. Press the **A** button  to accept.

### ***Option 3: Recording All Episodes***

**Tip:** Use this so you don't miss any episodes of your favorite shows.

When you first set up a recording (see above), instead of choosing **Record this Show**, use the **UP** arrow button to select **Record All Episodes** and press the **SELECT** button.

**Use your Back button on your browser to return to Answers on Demand Home Page.**