

## DVR: Watching Shows

### Watching Saved Shows

Any time you want, you can watch a show you've recorded. With DVR, you can even start watching a show from the beginning when you're in the middle of recording it!

1. Press the **LIST** button  to see your list of saved shows.



2. Use the **UP/DOWN** arrow buttons  to browse the list.

3. When you find the program you want, press the **SELECT** button .

4. The following list of options will pop up:

- **Play** - Start watching your show
- **Block** - So you control who can see it
- **Erase** - Erases your show
- **Change Save Time** - You can choose a save option
- **Copy to VCR** - You can copy a saved show to tape

5. To watch a show use the **UP/DOWN** arrow buttons then press the **SELECT** button. Note: If you have already watched part of a show, you will be given the option to **Play From Beginning** or **Resume Playback** instead.

**Tip:** Even if a show is currently in progress, you can watch it from the beginning, right then and there, by following the steps above.

6. Once the program begins, you can use the **PAUSE**, **PLAY**, **REWIND**, and **FASTFORWARD** buttons



as you would with a VCR.

**Tip:** To rewind or fast-forward at different speeds, try pressing these buttons once, twice or 3 times for the fastest speeds.

**Use your Back button on your browser to return to Answers on Demand Home Page.**