

## Remote Control: Program Your Remote

### What is a Universal Remote?

Your Digital Remote Control is a Universal Remote that can control your cable box, TV, VCR and Stereo (on some models). This allows you to control all your equipment without using separate remote controls.

In order for your remote to work on all your equipment, your remote must be programmed for your own equipment.

### How to Program Your Remote

1. Your cable installer may have already programmed your remote for some of these functions. If this not done, you can program your remote yourself. You may also need to program your remote if you move your TV, get new equipment, or the batteries on your remote expire.
2. For complete instructions, view the specific user manual for your remote. You'll get the codes for your specific brands of equipment and step-by-step instructions. If you have any problems, call customer service.

### Using Your Remote

Once your remote is programmed, you can use it for all of your equipment:

1. Press the **VCR** button to control your VCR.
2. Press the **CBL** button to control your cable box.
3. Press the **TV** button to control your TV.
4. Press the **AUD** button to control your stereo receiver.

**Note:**

The **AUD** button is not available on some remote models.

**Use your Back button on your browser to return to Answers on Demand Home Page.**